Building a GUI for Seismic Data Aquisition using Python

Name: Sankarshan Mondal 2nd Year BSMS, IISER Kolkata Summer 2023

Instructor: Dr. Dibakar Ghoshal Assistant Professor, Department of Earth Sciences IIT Kanpur

> Kanpur, Uttar Pradesh India June 22, 2023

Contents

1	Introduction	2
2	Objectives	2
3	Methodology3.1 GUI Design3.2 Data Acquisition3.3 File Generation	2 2 2 2
4	Functionality of the GUI	3
5	Conclusion	3
6	Demonstration of the GUI	3
7	Source Code	7

Acknowledgements

I would like to express my sincere gratitude and appreciation to all those who have contributed to the successful completion of the project involving the development of a GUI for seismic data acquisition and processing using Python and the Tkinter module.

First and foremost, I would like to extend my heartfelt thanks to my supervisor, Dr. Dibakar Ghoshal, for his guidance, support, and valuable insights throughout the project. His expertise and constant encouragement played a crucial role in shaping the project and overcoming various challenges.

I am grateful to the institution, IIT Kanpur for providing the necessary resources, including access to seismic data, software, and computing infrastructure. These resources were vital for the development and testing of the GUI, ensuring its functionality and performance.

Furthermore, I extend my appreciation to the individuals who generously shared their knowledge and expertise during the course of this project. Their valuable insights and suggestions significantly influenced the design and functionality of the GUI, enhancing its usability and effectiveness.

In conclusion, this project has been a collaborative effort, and I am truly thankful to everyone who has been a part of it. Your contributions, guidance, and support have been invaluable, and I am grateful for the opportunity to work on such an exciting and meaningful project.

1 Introduction

The purpose of this report is to provide an overview of a project involving the development of a Graphical User Interface (GUI) for seismic data acquisition and processing. The GUI has been built using Python programming language, utilizing the Tkinter module. This report outlines the project's objectives, the methodology used, and the resulting functionalities of the GUI.

2 Objectives

The main objectives of this project were as follows: - Develop a user-friendly GUI for seismic data acquisition and processing. - Implement functionalities for data acquisition from seismic sensors. - Generate four different output files containing processed seismic data.

3 Methodology

The project utilized Python as the programming language due to its simplicity, versatility, and wide range of available libraries. Tkinter, a standard GUI toolkit for Python, was chosen for building the graphical interface. The project followed an iterative development approach, including the following steps:

3.1 GUI Design

The initial phase involved designing the graphical layout of the user interface. This included selecting appropriate widgets, such as buttons, labels, and text boxes, to facilitate user interaction. The GUI design aimed to be intuitive, ensuring ease of use for users with varying levels of technical expertise.

3.2 Data Acquisition

The next step was to implement functionalities for data acquisition from seismic sensors. The GUI provided options to select the sensor, set acquisition parameters (e.g., sample rate, duration), and initiate data capture. The acquired data was stored in memory for further processing.

3.3 File Generation

The final step involved generating four different output files containing the seismic data. These files were saved in four formats- sps, rps, xps and txt to ensure compatibility with other applications. Each file contained specific information, such as Shot data, Receiver data, relation between shot and receiver and timestamp data, depending on the user's requirements.

Page 2

4 Functionality of the GUI

The developed GUI offered the following key functionalities:

- 1. Data Acquisition
 - (a) Setting acquisition parameters (sample rate)
 - (b) Initiating data capture
- 2. File Generation
 - (a) Four output files containing seismic data in different formats
 - *.sps (Shot Data)
 - *.rps (Receiver Data)
 - *.xps (Relation Data)
 - *.txt (Time Data)
 - (b) Options to generate the specific data to be included in each file

5 Conclusion

In conclusion, the project successfully developed a GUI for seismic data acquisition using Python and the Tkinter module. The GUI provided a user-friendly interface for acquiring data from seismic sensors. It allowed the generation of three output files containing the seismic data. This project serves as a valuable tool for researchers, geophysicists, and professionals working with seismic data, enabling efficient data analysis and reporting. Further enhancements and features can be added to the GUI to meet specific user requirements in the future.

6 Demonstration of the GUI

The GUI can be used when we have four files in the same directory. In other words it is of the form of a folder containing three files and a two folders. They are the following:

- 1. python 3.py
- 2. header: This is a folder containing the following files:
 - (a) receiver.txt
 - (b) relation.txt
 - (c) shot.txt
- 3. **plot**: This folder is required for the graphical representation. If this folder is not present, please create an empty folder with the name 'plot'.

The file inputs we need are the time files in .csv format (preferably).

The step by step way to use the GUI is as follows:

Step 1

Open the terminal. Change the directory to the folder by using the following command:

cd ~/Desktop/sankarshan_2023

First run the python file in the terminal using python command:

python3 project_3.py

You will observe a GUI which looks like this:




Figure 1: The GUI

Step 2

Start filling up the data in the following order:

- 1. File Info
- 2. Shot Data
- 3. Receiver Data
- 4. Relation Data
- 5. Time Data

Step 3

part 1

Fill up the 'File Info' box and click the **Create Folder** button. This will create a folder with the filename entered. It will contain an empty folder named **csv**.

The time files should be of the form *timestamp*.csv where *timestamp* is the name of the file with **csv** extension. After making the folder with the 'File Info' box, carefully move the *timestamp*.csv file corresponding to that dataset to a folder called **csv**. This folder will be formed inside the folder formed with the name, **filename**.

part 2

Click the respective button in every box after filling up the information in a box. Do not worry if you fill up any wrong information by mistake. Correct the value in the textbox and click the button. Your wrong value will be overwritten.

part 3

Fill up the name of the csv file carefully (complete with the extension). Also make sure that the time file corresponds to the number/index of the shot and receiver combination used i.e. be careful in moving the respective csv files to their respective folders.

part 4

For the filename, you can not create folder with the same file name multiple times. To use the same file name, you have to manually remove the existing folder with the same name. Or else the data inside the folder will be overwritten with the new data input. If you are willing to change any data in a folder you have already created, just type the name of the folder, and the index in the 'File Info' box and start filling out rest of the boxes, this would do the job.

Step 4

Once you have filled up all the boxes you will see a folder (by the name entered as input) in the directory. This folder consists of four new files of the following formats:

- 1. *.sps (Shot Data)
- 2. *.rps (Receiver Data)
- 3. *.xps (Relation Data)
- 4. *.txt (Time Data)

It would also have a folder named **csv**. Inside **csv**, we would have the original *timestamp*.csv file.

We can use this folder (which has the same name as the files) for analysis. It is good idea to transfer this folder to a different directory.

Step 5

There is a button at the very end which says: Click to see the location graph. Clicking this will show you a graph like the following:




Figure 2: The interactive plot

This interactive plot shows the position of source and receiver during a single measurement. The **star** sign represents the source, the **triangle** represents the receivers. Each measurement is represented by different colours. The source is also indexed according to the Shot Data File.

7 Source Code

The total code used for the GUI is as follows:

```
1 from tkinter import *
from PIL import Image, ImageTk
3 import pandas as pd
4 import os
5 import numpy as np
6 from datetime import datetime
7 import time
8 import matplotlib.pyplot as plt
9 import matplotlib.cm as cm
11
13 \text{ root} = Tk()
root.title("2D SPS Generator")
root.iconphoto(False, PhotoImage(file = 'seismo.png'))
18 frame0 = LabelFrame(master=root, text="File Info")
19 frame0.grid(row=0, column=0, columnspan=2, pady=20, padx=20)
label_name = Label(frame0, text="Choose a file name:")
label_name.grid(row=0, column=0, pady=12, padx=10, sticky='ew')
1_n_e = Entry(frame0)
l_n_e.grid(row=0, column=1, pady=12, padx=10, sticky='ew')
27 index = Label(frame0, text="Choose a two digit index (10-99):")
index.grid(row=1, column=0, pady=12, padx=10, sticky='ew')
30 index = Entry(frame0)
index.grid(row=1, column=1, pady=12, padx=10, sticky='ew')
32
33 def f():
     os.mkdir("{}".format(l_n_e.get()))
      os.mkdir("{}/csv".format(l_n_e.get()))
35
37
38 global dir
39 dir = os.getcwd()
41 button0 = Button(frame0, text="Create Folder", command=f, bg="black", fg="white")
42 button0.grid(row=2, column=0, columnspan=2, pady=12, padx=10, sticky='ew')
43
44
45
46
48 frame1 = LabelFrame(master=root, text="Shot Data")
49 frame1.grid(row=1, column=0, pady=20, padx=20)
frame2 = LabelFrame(master=root, text="Receiver Data")
frame2.grid(row=1, column=1, pady=20, padx=20)
54 frame3 = LabelFrame(master=root, text="Relation Data")
frame3.grid(row=2, column=0, pady=20, padx=20)
57 frame4 = LabelFrame(master=root, text="Time Data")
frame4.grid(row=2, column=1, pady=20, padx=20)
61 label = Label(root, text="Please pass only Positive integers in the text boxes")
label.grid(row=3, column=0, columnspan=2, sticky='ew')
64 f_s = Label(frame1, text="First Shot:")
```

```
65 f_s.grid(row=0, column=0, pady=12, padx=10)
67 f_s_e = Entry(frame1)
f_s_e.grid(row=0, column=1, pady=12, padx=10)
70
71 n_s = Label(frame1, text="Number of Shots:")
n_s.grid(row=1, column=0, pady=12, padx=10)
74 n_s_e = Entry(frame1)
n_s_e.grid(row=1, column=1, pady=12, padx=10)
78 d_s = Label(frame1, text="Shot Spacing (m):")
79 d_s.grid(row=2, column=0, pady=12, padx=10)
81 d_s_e = Entry(frame1)
82 d_s_e.grid(row=2, column=1, pady=12, padx=10)
83
85 n_r = Label(frame2, text="Total number of Receivers:")
n_r.grid(row=0, column=0, pady=12, padx=10)
n_r_e = Entry(frame2)
89 n_r_e.grid(row=0, column=1, pady=12, padx=10)
91
92 d_r = Label(frame2, text="Receiver Spacing (m):")
93 d_r.grid(row=1, column=0, pady=12, padx=10)
94
d_r_e = Entry(frame2)
d_r_e.grid(row=1, column=1, pady=12, padx=10)
98 #-----
99
def shot_f(x,y):
101
102
103
      #Take into input Shots
      shot = int(x)
104
      shot+=1
105
106
      #We form a list to index the shots. This way we would be able to track the data
107
      global shot_n
108
109
      shot_n=[]
      for i in range(shot):
110
          num = str(int(index.get())*1000+i+int(f_s_e.get()))
          shot_n.append(num + "1E1")
112
113
114
      #Lattitude
115
      \#We don't take the lattitude from a file and store it into a list. Ordered values
116
       are preferred
      lat = [0.0 for i in range(shot)]
117
118
      #Longitude
120
      #We don't take the longitude from a file and store it into a list. Ordered values
121
       are preferred
      long = [0.0 for i in range(shot)]
122
123
124
126
      #Elevation
127
      #We don't take the elevation from a file and store it into a list. Ordered values
       are preferred
     elev = [0.0 for i in range(shot)]
129
```

```
130
131
        #We also obtain the shot value from a file
133
        #example file
134
135
136
       #shot offset due to shot spacing
137
       shot_v = float(y)
138
139
140
       #We convert it into float as this is the last entry in the row and we want to
141
        move to the next row.
       so = []
142
143
        for x in range(shot):
           n = 0 + x*shot_v
144
           so.append(n)
145
146
       #thing for formatting
147
       S1 = ["S1" for i in range(shot)]
space1 = [" "*16 for i in range(shot)]
148
149
        #index
150
        space2 = [" "*1 for i in range(shot)]
        zero1 = ["0" for i in range(shot)]
152
        #lattitude
153
        space3 = [" "*1 for i in range(shot)]
154
        zero2 = ["0 0" for i in range(shot)]
155
       #longitude
156
        space4 = [" "*2 for i in range(shot)]
157
       #offset
158
       space5 = [" "*5 for i in range(shot)]
159
       #elevation
160
       space6 = [" " for i in range(shot)]
161
162
       #some zeroes
       number = [" 1235959" for i in range(shot)]
163
164
165
166
       df = pd.DataFrame({"S1":S1, "Space1":space1,"Shot_no": shot_n, "space2":space2, "
zero1":zero1, "Lattitude": lat, "space3":space3, "zero2":zero2, "Longitude": long
, "space4":space4, "Shot_offset": so, "space5":space5, "Elevation": elev, "space6
167
        ":space6, "zeroes":elev, "number":number})
168
169
       with open("header/shot.txt") as f:
170
            os.chdir("{}".format(l_n_e.get()))
171
            with open("{}.sps".format(l_n_e.get()), "w") as f1:
172
                 for line in f:
173
                     f1.write(line)
174
175
                 f1.write("\n")
                 df_string = df.to_string(header=False, index=False)
176
                 f1.write(df_string)
177
178
            os.chdir(dir)
179
       with open('plot/data_s_plot.txt', 'w') as f:
180
            df_string = df.to_string(header=False, index=False)
181
            f.write(df_string)
182
183
184 #-----
185
186 def receiver_f(x,y):
187
188
189
        #Take into input Shots
       shot = int(x)
190
191
       #We form a list to index the shots. This way we would be able to track the data
192
      s=[]
193
```

```
for i in range(1,shot+1):
194
195
            num = str(2000+i)
            s.append(num + "1G1")
196
197
198
        #Lattitude
199
        #We take the lattitude from a file and store it into a list. Ordered values are
200
        preferred
201
        lat = [0.0 for i in range(shot)]
202
203
204
        #Longitude
205
        #We take the longitude from a file and store it into a list. Ordered values are
206
        preferred
        long = [0.0 for i in range(shot)]
208
209
210
211
212
        #Elevation
213
        #We take the elevation from a file and store it into a list. Ordered values are
214
        preferred
215
216
        elev = [0.0 for i in range(shot)]
217
218
219
        #We also obtain the shot value from a file
        #example file
220
221
        #shot offset due to shot spacing
222
223
224
        re_v = float(y)
225
226
        #We convert it into float as this is the last entry in the row and we want to
227
        move to the next row.
228
        re = []
        for x in range(shot):
229
           n = 0 + x*re_v
230
231
           re.append(n)
232
        #thing for formatting
233
234
        S1 = ["R1" for i in range(shot)]
        space1 = [" "*17 for i in range(shot)]
235
236
        #index
        space2 = [" "*1 for i in range(shot)]
237
        zero1 = ["0" for i in range(shot)]
238
239
        #lattitude
        space3 = [" "*1 for i in range(shot)]
240
        zero2 = ["0 0" for i in range(shot)]
241
242
        #longitude
        space4 = [" "*2 for i in range(shot)]
243
        #offset
244
        space5 = [" "*5 for i in range(shot)]
245
        #elevation
246
        space6 = [" " for i in range(shot)]
247
        #some zeroes
248
        number = [" 1235959" for i in range(shot)]
249
250
251
252
        df = pd.DataFrame({"S1":S1, "Space1":space1,"Shot_no": s, "space2":space2, "zero1
":zero1, "Lattitude": lat, "space3":space3, "zero2":zero2, "Longitude": long, "
        space4":space4, "Receiver_offset": re, "space5":space5, "Elevation": elev,
space6":space6, "zeroes":elev, "number":number})
254
```

```
255
       with open("header/reciever.txt") as f:
256
          os.chdir("{}".format(l_n_e.get()))
257
           with open("{}.rps".format(l_n_e.get()), "w") as f1:
258
               for line in f:
259
                   f1.write(line)
260
261
               f1.write("\n")
               df_string = df.to_string(header=False, index=False)
262
               f1.write(df_string)
263
           os.chdir(dir)
264
265
266
       with open('plot/data_r_plot.txt', 'w') as f:
267
           df_string = df.to_string(header=False, index=False)
268
           f.write(df_string)
260
271 #-----
272
273 def relation(x,y):
274
275
276
277
       #Importing the shot data from a random column
278
       df_s = pd.read_fwf("plot/data_s_plot.txt", usecols=[1], names=['index'])
       #print(df_s)
279
280
       #Importing the reciever data from a rqandom column
281
       df_r = pd.read_fwf("plot/data_r_plot.txt", usecols=[1], names=['index'])
282
       #print(df_r)
283
284
       #Selecting the starting reciever on the basis of data obtained from shot position
285
       and reciever position
286
287
       p = [x for x in df_r["index"]]
       q = [x for x in df_s["index"]]
288
289
290
       #print(p,q)
291
292
       #using loops to find where the shot data matches the reciever
293
       #the first active receiver
294
295
       print("Press enter if all recievers are working")
296
       active = int(x)
297
       working = int(y)
298
       if 0<active<len(p):</pre>
299
           if active < working < len(p):</pre>
300
               p = p[active-1:working]
301
           else:
302
               label = Label(root, text="Use number between {} and {}".format(active,
303
       len(p)))
               label.grid(row=3, column=0, columnspan=2)
304
305
          label = Label(root, text="Too large number")
306
           label.grid(row=3, column=0, columnspan=2)
307
       print("wow")
309
310
311
       shot = len(q)
312
313
       #defining indices for measurement
       s=[]
314
       for i in range(shot):
315
316
          num = str(int(index.get())*1000+i+int(f_s_e.get()))
           s.append(num + "1")
317
318
       print(s)
319
    #starting reciever
320
```

```
r_s = [active for i in s]
321
322
       #print(r_s)
323
       #last reciever
324
       r_e1 = [working for i in s]
325
       r_e = []
326
       for i in r_e1:
    n = " {x}11".format(x = i)
327
328
           r_e.append(n)
329
330
       #print(r_e)
331
332
333
       #exact starting reciever
334
335
       r_s1 = []
       for i in range(active, active+shot):
336
          n = 2000 + i
337
338
           r_s1.append(n)
       #print(r_s1)
339
340
       #exact ending reciever
341
       r_s2 = []
342
343
       for i in range(working, working+shot):
344
           n = 20000 + i*10 + 1
           r_s2.append(n)
345
346
       #print(r_s2)
347
348
349
       #things for formatting the text file
350
       R1 = ["X0" for i in range(shot)]
space1 = [" "*7+"0111"+" "*17 for i in range(shot)]
351
352
       #index
353
       space2 = [" "*1 for i in range(shot)]
354
       #starting_receiver
355
       #last receiver
356
       space3 = [" "*17 for i in range(shot)]
357
       #reciver_start
358
       space4 = [" "*2 for i in range(shot)]
359
       #reciver_end
360
361
362
363
364
365
       #forming the dataframe by pandas
       dataset = {"X0":R1, "space1":space1, "Index":s, "space2":space2, "Start": r_s,
366
       End": r_e, "space3":space3, "start_reciever_ID":r_s1, "space4":space4, '
       end_reciever_ID":r_s2}
       dataframe = pd.DataFrame(dataset)
367
368
369
       with open("header/relation.txt") as f:
370
           os.chdir("{}".format(l_n_e.get()))
371
           with open("{}.xps".format(l_n_e.get()), "w") as f1:
372
               for line in f:
373
                    f1.write(line)
               f1.write("\n")
375
376
               df_string = dataframe.to_string(header=False, index=False)
               f1.write(df_string)
377
           os.chdir(dir)
378
379
380
       with open("plot/data_relation.txt", "w") as f1:
381
               df_string = dataframe.to_string(header=False, index=False)
               f1.write(df_string)
383
384
     ______
385 #
386
```

```
387
388 button1 = Button(frame1, text="Make the shot file", command=lambda: shot_f(n_s_e.get
      (),d_s_e.get()), bg="black", fg="white")
sse button1.grid(row=3, column=0, columnspan=2, pady=12, padx=10, sticky='ew')
390
391
392
393 button2 = Button(frame2, text="Make the receiver file", command=lambda: receiver_f(
     n_r_e.get(),d_r_e.get()), bg="black", fg="white")
394 button2.grid(row=2, column=0, columnspan=2, pady=12, padx=10, sticky='ew')
395
396
398 relation1 = Label(frame3, text="First Active receiver:")
relation1.grid(row=0, column=0, pady=12, padx=10, sticky='ew')
401 relation1_e = Entry(frame3)
402 relation1_e.grid(row=0, column=1, pady=12, padx=10, sticky='ew')
403
404
relation2 = Label(frame3, text="Last Active receiver:")
406 relation2.grid(row=1, column=0, pady=12, padx=10, sticky='ew')
407
408 relation2_e = Entry(frame3)
409 relation2_e.grid(row=1, column=1, pady=12, padx=10, sticky='ew')
410
411
412
413 button3 = Button(frame3, text="Make the relation file", command=lambda: relation(
      relation1_e.get(), relation2_e.get()), bg="black", fg="white")
414 button3.grid(row=2, column=0, columnspan=2, pady=12, padx=10, sticky='ew')
417
label1 = Label(frame4, text="Acquisition length (milisec):")
label1.grid(row=0, column=0, pady=12, padx=10, sticky='ew')
421 label1_e = Entry(frame4)
122 label1_e.grid(row=0, column=1, pady=12, padx=10, sticky='ew')
424
125 label2 = Label(frame4, text="RECORD LENGTH (milisec):")
label2.grid(row=1, column=0, pady=12, padx=10, sticky='ew')
427
428 label2_e = Entry(frame4)
label2_e.grid(row=1, column=1, pady=12, padx=10, sticky='ew')
430
label3 = Label(frame4, text="Time Shift (sec):")
432 label3.grid(row=2, column=0, pady=12, padx=10, sticky='ew')
433
434 label3_e = Entry(frame4)
label3_e.grid(row=2, column=1, pady=12, padx=10, sticky='ew')
436
437
438 timefile = Label(frame4, text="Write the name of the excel file correctly:")
439 timefile.grid(row=3, column=0, pady=12, padx=10, sticky='ew')
440
441 timefile_e = Entry(frame4)
442 timefile_e.grid(row=3, column=1, pady=12, padx=10, sticky='ew')
443
444
445 def time_f():
446
447
       df = pd.read_csv(l_n_e.get() + '/csv/' + timefile_e.get(), sep=",")
448
       a = ["1/6/1980" for i in range(len(df.index))]
449
450
      print(a)
451
```

```
df["fix"] = a
452
453
       df["fix"] = pd.to_datetime(df["fix"])
454
       df["Time"] = pd.to_datetime(df["Time"])
455
456
       print(df['fix'])
457
458
459
       df["diff"] = ((df["Time"] - df["fix"]).dt.total_seconds() + int(label3_e.get()))
460
       *10**6
       print(df["diff"])
461
462
463
464
       description = ["Impulsive" for i in range(len(df.index))]
465
       src_l = [1 for i in range(len(df.index))]
466
       src_s = []
467
468
        for i in range(len(df.index)):
           num = str(int(index.get())*1000+i+int(f_s_e.get()))
469
            src_s.append(num + "1")
470
471
       ffid = []
472
       for i in range(len(df.index)):
473
474
            num = str(int(index.get())*1000+i+int(f_s_e.get()))
            ffid.append(num + "1")
475
476
477
       acq = [label1_e.get() for i in range(len(df.index))]
       rec = [label2_e.get() for i in range(len(df.index))]
478
479
       sweep = [0 for i in range(len(df.index))]
480
       blast = [6 for i in range(len(df.index))]
481
       exit_s = [1024 for i in range(len(df.index))]
482
       exit_t = [0,0.3,0.2,0.9] + [0.2 for i in range(len(df.index)-4)]
483
484
485
486
487
       df1 = pd.DataFrame({"DESCRIPTION":description, "GPS TIMESTAMP":df["diff"], "SRC
LINE":src_1, "SRC STATION":src_s, "FFID":ffid, "ACQ LENGTH":acq, "PROCESS TYPE":
488
       src_l, "STACKING FOLD":src_l, "ACQ NUMBER":src_l, "RECORD LENGTH":rec, "SWEEP
       LENGTH": sweep, "AUTOCORREL PEAK": sweep, "CORREL TRACE NUMBER": sweep, "TYPE OF
       DUMP":sweep, "SOURCE TYPE":src_1, "UPHOLE TIME":sweep, "BLASTER ID":blast,
       BLASTER STATUS":sweep, "EXT HEADER SIZE":exit_s, "EXT HEADER TEXT":exit_t})
489
       os.chdir("{}".format(l_n_e.get()))
490
       df1.to_csv("{}.txt".format(l_n_e.get()), sep=",")
491
       os.chdir(dir)
492
494 Button4 = Button(frame4, text="Compile time Data", command=time_f, bg="black", fg="
       white")
495 Button4.grid(row=4, column=0, columnspan=2, pady=12, padx=10, sticky='ew')
496
497 def plot_g():
498
       df_s = pd.read_csv("plot/data_s_plot.txt", sep = "\s+", header=None)
499
500
       df_r = pd.read_csv("plot/data_r_plot.txt", sep = "\s+", header=None)
501
502
       #df_rel = pd.read_csv("data_relation.txt", sep = "\s+", header=None)
503
504
505
       a = int(relation2_e.get())
506
       b = int(relation1_e.get())
507
508
       source = np.array(df_s[7])
509
       receiver = np.array(df_r[7])
511
print(source)
```

```
513
       x = np.arange(len(source))
514
       ys = [i+x+(i*x)**2 for i in range(len(source))]
515
516
517
       colors = cm.rainbow(np.linspace(0, 1, len(ys)))
518
519
520
       ax = plt.gca()
521
       i = 0
522
       for j, k in zip(range(len(source)), colors):
523
           plt.scatter(receiver[b-1+j+1:b-1+a+j-1], [-source[j] for i in range(b+1, a)],
524
        marker="^", color=k)
          plt.scatter(source[j], -source[j], marker="*", color='black')
525
           plt.text(source[j], -source[j], shot_n[i][:len(shot_n[i])-2])
526
           i+=1
527
528
       plt.ylabel("Varying Source")
529
       ax.axes.yaxis.set_ticklabels([])
530
       plt.title("Acquisition Geometry")
plt.xlabel("Offset")
531
532
       plt.show()
533
534
535 button5 = Button(root, text="Click to see the location graph", command=plot_g, bg="
      black", fg="white")
button5.grid(row=4, column=0, columnspan=2)
537
538
539 root.mainloop()
```

THANK YOU